DZONEEZ

Quick Start Guide

V1.0




For X701, X501


www.droneer.com


Pre-Takeoff Precautions

- 1. Ensure the drone is undamaged, batteries have no swelling/leakage, equipment is properly connected, and VTX is stable.
- 2. Confirm propellers rotate in the correct direction and screws are securely fastened.
- 3. Ensure the battery is tightly secured with straps.
- 4. Ensure the battery is fully charged.
- 5. Turn on the remote control, select the correct mode, and confirm the unlock switch is locked with the throttle at the lowest position.
- 6.Check for frequency conflicts between FPV goggles and the screen.
- 7. After powering on the drone, maintain a 1-meter safety distance for test unlocking.
- 8. Take off only in areas permitted by local laws/regulations.
- 9. Fly in locations with good GNSS signal reception.

Battery Installation







3

GPS Rescue

1. Basic GPS Rescue Mode Setup

The GPS rescue mode automatically guides the drone back when the remote control signal is lost (triggering Failsafe) or manually activated by the pilot. If not specifically configured with an AUX switch for control, the system triggers automatically during signal loss. Users with digital video transmission systems like DJI can visually monitor the rescue status, while analog video transmission users must obtain info thru OSD overlavs.

2. Core Parameter Configuration Instructions

The recommended initial height is set to 20-50m, which serves as the starting climb height for the drone's return: the recommended return speed is 5-10m/s; and satellites' no. is recommended to be ≥ 8 There are 2 altitude modes: MAX (maximum altitude) and FIXED (fixed value), which can be selected as needed. The throttle hover value is generally auto-calibrated, and the system will auto-calculate it.

3. Advanced Settings Options

In expert mode, there are more advanced settings, The default motor shutdown delay is 0.1 seconds. which controls the time for motors to stop after fail-safe activation. The landing throttle value applies to the normal "landing" mode and is unrelated to GPS rescue. The recommended climb and descent rates

are ≤3 m/s and ≤2 m/s, respectively, to ensure smooth operation. These advanced parameters need fine-tuning according to the flight environment and aircraft model.

4. Test and Verification Key Points

Before using this function, fully testing is required. For the first test, choose an open area and manually trigger the rescue mode rather than waiting for failsafe activation to better observe the FPV's response. The FPV should fly straight for at least 100m to verify GPS positioning accuracy, particularly confirming whether the "home arrow" indicates the correct direction. Environmental factors affect GPS performance—adverse weather conditions reduce available satellites' no., while obstacles like tall buildings & mountains degrade positioning accuracy, potentially causing the rescue function to fail.

5. Important Safety Notes

The GPS rescue mode is fundamentally different from fully automatic return to home (RTH) and serves as an emergency backup, not a complete reliance. Before use, adjust parameters according to the specific aircraft model (wheelbase, power configuration, etc.).


6. GPS Rescue Mode Parameter Settings:



Warning: The drone can only return when there are ≥ 10

Propeller Installation Tips

Propellers with marks and those without marks indicate different rotation directions respectively. It is necessary to strictly follow the instructions to install different propellers in their corresponding positions.




起飞前注意事项

- 1. 确保机体无损坏、电池无起心,前注意事正 常、图传稳定。
- 2.确认螺旋桨转向正确,螺丝冠铁烧体无损坏、电池 3.确保绑带将电池绑紧。 常、图传稳定。
- 4.确保电池电量充足。 2.确认螺旋桨转向正确.
- 5.打开遥控器,选择正确的模缝保绷带条件排货处处 于上锁状态,油门位置在具作,电池电量充足。
- 6.检查FPV 眼镜和屏幕是否有频率速控器,选择正确
- 7. 飞机上电后,保持1米的安全距离进冷测调解镀置 8.请在当地法律法规允许的这个产品,眼镜和屏幕是
- 9.请在GNSS信号良好地方飞飞机上电后,保持1米

 - 8.请在当地法律法规允许
 - 9.请在GNSS信号良好地

电池安装



3

GPS救援

1. GPS救援模式基础设置

GPS 救援模式用于遥控信号丢失(触发失控保护)或 飞手手动激活时,自动引导无人机返回。若未专门配置 AUX 开关控制、失控时系统自动触发。使用 DJI 等数字 图传 系统可直观显示救援状态,模拟图传用户需通过 OSD叠加信息获取。

2. 核心参数配置说明

初始高度建议设为20-50m,是无人机返航起始爬升高 度:返航速度建议5-10m/s:卫星数建议>8颗。高度模 式有MAX (最大高度) 和FIXED (固定值) 两种, 按需 选择。油门悬停值一般自动校准,系统会自动计算。

3. 高级设置选项

专家模式下有更多高级设置。电机停转延迟默认0.1秒 . 控制失控保护触发后电机停转时间。降落油门值用于 普诵"降落"模式。与GPS救援无关。爬升、下降读率建 议分别<3m/s和<2m/s,确保平稳。这些高级参数需依 飞行环境和机型微调。

4. 测试验证要点 使用此功能前,须进行充分测试。首次测试选开阔场地 建议手动触发救援模式而非等待失控保护触发, 以便 更好地观察FPV反应。需让FPV直线飞行至少100m 以验证GPS定位精度、特别要确认"家箭头"指示方向是 否正确。环境因素会影响GPS性能、恶劣天气条件会减 少可用卫星数量,而高楼、山脉等遮挡物会降低定位精 度,可能导致救援功能失效。

5. 重要安全须知

GPS救援模式与全自动返航 (RTH) 本质不同, 是应急 备用方案,不可完全依赖。使用前,要依具体机型(轴 1. 距、动力配置等)调整参数。


6. GPS救援模式参数设置:



警告: GPS≥10颗卫星才可以返回。

螺旋桨安装提示

带标记和不带标记的螺旋桨分别指示了不同的旋转方 向, 需严格按照指示, 安装不同的螺旋桨至相应的位





Web: www.droneer.com Email: marketing@droneer.com

Shenzhen Zhimu Technology Co., Ltd. reserves the right of

final interpretation.



























